


PRESIDENT JFK

ALIGNMENT POINTS =====

PC - 713 MAIN PCB



PC - 904 FM MODULE

